

# OPERATOR ALERT

## Back-Up Monitor Brightness Control

Vehicle Maintenance has installed a push button back-up monitor brightness controller in the cab of LRV-142 as a pilot test bed.

There are two settings that may be selected by pushing the dimmer enable/disable button near the lower monitor frame.

Pushing once while the monitor is bright will cause the screen (monitor) to dim.

Pushing once while the screen is dim will cause the screen (monitor) to brighten.



David Vestal  
Operations Chief  
Post until 9/20/18